



Touch Lighting



Napkin Feeding Area



Water call screen

Water call button



Rechargeable Battery



Wireless Phone Charging Area

Twin Model



1 Wireless Phone Charging Area

It is a section that consists of at least two sections, one on the right and the left of the device, and allows the phone to be charged wirelessly via induction.

2 USB Charging Area

It is the USB Charging Connection section, which is available on the device upon the user's request and is an alternative to wireless charging. Located on both sides of the device, right and left

3 Napkin Feeding Area

It is the part that protects the napkin holder and the system inside from external influences. It automatically gives the wet / dry napkins to the user with the motion sensors and motor system inside. This part can be one or more.

4 Napkin Output Sensor

It is the sensor that measures how much of the napkin will come out and be given to the user. The napkin length here is adjusted by the software. When it reaches a certain distance, the movement of the napkin rolls stops.

5 Disinfectant Section

It is the part that sprays when the user approaches with his hand, thanks to the sensors on it. This section allows you to use it in a sterile and hygienic manner without touching the disinfectant bottle with your hand. It is located in the middle part of the device. It automatically sprays disinfectant when your hand approaches, thanks to the pump motor inside.

6 Touch Lighting

It is the Touch Gradual Lighting section, which is activated by the sensitive detection system of the motion sensor on it and provides at least three gradual lighting opportunities within itself.

7 Spices Section

This is the area on the device where desired products such as spices/salt can be placed.


8 Waiter Call Button

It is the button that shows which table is calling by pressing the button on the device, either by monitoring it on the computer screen or by transferring it to the television screen. When the waiter call process is activated on this button, the light flashes and allows the waiter to come to your table quickly. With the button on the device, it sends signals to the screens placed at certain points and the screen shows which table the call is received from.

MULTIFUNCTIONAL DESK TOP SERVICE DEVICE

Single Model

Twin Model



MFS DEVICE
Elektronik Servis Cihazları San. ve Dış Tic. Ltd. Şti.

STAINLESS SERIES



Special Coating (Optional)

ALUMINIUM SERIES



Special Coating (Optional)

COLORED SERIES (DKP METAL)

• Electrostatic Paint Coating



Special Coating (Optional)

Water Transfer Printing



Special Coating (Optional)

You can choose special paint's (optional)



MFS DEVICE
Elektronik Servis Cihazları San. ve Dış Tic. Ltd. Şti.

Abdurrahmangazi Mh. Said Sk.
No:10 D:4, Sultanbeyli/İstanbul
+90 216 419 59 52

info@mfsdevice.com
www.mfsdevice.com
+90 533 627 56 00